



IDEAL WAREHOUSE
INNOVATIONS INC

Protecting Your People

Back-SavR Installation Guidelines

1. Hang the Back-SavR vertically on the safety cage in the desired location.
Create a 5/8" clearance at the top of the safety cage.
2. Accurately mark two holes on the body of the truck for the bottom bracket.
3. Remove the Back-SavR.
4. **Look behind what you are drilling on the truck to make sure there are no wires, electronic circuit boards, or other objects you do not wish to damage. Ensure there is enough clearance for the bolts.**
5. Center punch the hole location for accurate drilling of the holes.
6. Drill and/or tap as needed.
7. Hang the Back-SavR on the safety cage and install bottom bolts snugly.
Align vertically and tighten top bolt to safety cage snugly. Then tighten very top bolt.
8. Tighten all bolts securely.
9. Cut Knuffi® Bumper Guard to size and install as required.

