



STEP 1: POSITION GUARD INTO DESIRED LOCATION

STEP 2: FASTEN TO WALL WITH MINIMUM (3) 3/8" x 2-3/4" CONCRETE ANCHORS OR OTHER SUITABLE FASTENER

\* A LONG DRILL BIT MAY BE REQUIRED DEPENDING ON SURROUNDING CONDUIT OR EQUIPMENT

DRAWN BY: <b>T.CHUNG</b>	DATE: <b>2019-07-22</b>	 3rd Angle SIZE: <b>A</b>	 <b>IDEAL WAREHOUSE INNOVATIONS INC</b>
CHECKED BY:	DATE:		
THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF IDEAL WAREHOUSE INNOVATIONS INC. ANY REPRODUCTION IN PART OR AS A WHOLE IS PROHIBITED.		DESCRIPTION:	
		<b>TRACK PROTECTOR SLIM INSTALLATION INSTRUCTIONS</b>	
SCALE: <b>1:24</b>	SHEETS: <b>1 of 1</b>	DRAWING NUMBER: <b>60-40XX-INSTALL</b>	REV: <b>0</b>