



WARNING

RAPID ROLL SYSTEMS VISUAL BARRIER ONLY

DO NOT USE TO SECURE PERSONS OR MATERIAL. NOT TO BE USED AS A SAFETY/GUARD RAIL OR AS A PART OF A FALL ARREST SYSTEM. FAILURE TO COMPLY CAN RESULT IN SERIOUS INJURY/DEATH OR PROPERTY DAMAGE.

RAPID ROLL

OPERATING INSTRUCTIONS

- Cartridge operates in the vertical or horizontal position.
- Must be mounted on pedestal or fastened with ground stakes when in vertical position.
- The operator must add additional weight, such as sand bags, on the leg extensions of the cartridge base and post bases in windy or adverse conditions.
- To mount on the pedestal or ground stake use the middle and top carrying handle grips.
- When using base, ensure the (3) pedestal hold down clips are not bent or filled with debris.
- When using base, place cartridge on top of base; position the (3) cartridge foot tabs at the open end of the hold down clips and rotate counter-clockwise to lock. Reverse action to unlock cartridge.
- **CAUTION: Pinch Hazard!** At all times, when cranking, keep one hand on crank handle and the other on side carrying handle grip.
- When retracting barrier material turn cranking handle clockwise.
- NOTE: The Rapid Link system can also be used on the same cartridge.
- NOTE: For added security an owner supplied lock can be fitted into the provided hook holes on Rapid link grip.
- ****Failure to comply with operating instructions may result in serious injury/death or property damage!**
- Any questions or concerns with the use of this device contact the manufacturer.

Telephone: North America: +1.866.828.6737

International: +1.905.850.2155

RapidRoll™ is a brand of Ideal Warehouse Innovations, Inc.

www.rapidroll.ca

Made in Canada and USA | Patent Pending